

Turbo Brush Replacement Parts

No.	Product Name
1	104010 Top Cover
2	104011 1 1/4" Neck Assembly Complete
	104012 1 1/2" Neck Assembly Complete
3	103974 Bushing w/Holder
4	104014 Medium Orifice
5	104017 Back Wheel, Set of 2
6	104016 Rear Axle, Set of 2
7	104021 Bottom Cover
8	104018 Front Axle, Set of 2
9	104019 Front Wheel, Set of 2
10	104022 Squeegee
11	104020 Belt
12	104023 Belt Guard
13	103975 Brush Arm, Set of 2
14	104024 Brush Roller Assembly
15	106525 Screws, Set of 2

