

the MAXX® Multi-Purpose Stain & Odor Remover is an advanced fiber safe formula that performs unbelievably on tough stains and odors. Use on carpets, upholstery, clothes, reappearing stains, walls, countertops and floors.

• Kool-Aid®

Food Spills

·Coffee/Tea

•Grime

Vomit

Blood

Grease

Grass Stains

Pet Stains

Cola

•Berry

•Berry Stains •And much more





P: 224.654.6500

www.unoclean.com To Order Now





the MAXX® Multi-Purpose Stain & Odor Remover

Use on any water-safe surfaces or fabrics.



•Kool-Aid®
•Coffee/Tea

•Food Spills
•Grime & Grime

VomitGrease

•Blood
•Grass Stains

•Pet Stains

Cola

Berry Stains

•And much more

C515-009 Quarts 6/case

C515-005 Gallon 4/case

DIRECTIONS FOR USE Shake well before using.

Apply a small amount of product to an inconspicuous area. If surface discolors or fades do not use.

FOR CARPETS, UPHOLSTERY, CLOTHES:

- **1.** Spray stained area thoroughly with the MAXX®, wait one minute.
- 2. Agitate or work in with a carpet bone or spatula.
- **3.** Blot or gently rub area with a clean, absorbent cloth.
- **4.** Repeat until stain is removed.
- **5.** Blot any excess moisture.

FOR REAPPEARING STAINS:

Repeat Steps 1-3; then place a clean, white cloth over the treated area, followed by placing a weighted object on the towel. Wait until the towel absorbs excess stain residue and moisture that wicks to the top.

Remove stains promptly after they occur and avoid over-wetting of carpets or fiber surfaces.





P: 224.654.6500





