
ATTIX 33 - ATTIX 44 -ATTIX 33L - ATTIX 44L

Instructions for use































Operating elements







































































































Push&Clean
























InfiniClean


























































4D 5D






























Quick reference guide

Operating elements:

| 4 | ш | a | _ | الہ | ۱, |
|---|---|---|---|-----|----|
| 1 | н | a | n | a | ıe |

- 2. Accessory positions
- 3. Latch
- 4. Castor
- 5. Container
- 6. Inlet fitting
- 7. Switch
- 8. Speed control*)
- 9. Appliance socket*)
- 10. Filter cleaning button (Push&Clean)*)
- 11. Hose hook

The pictorial quick reference guide

The pictorial quick reference guide is designed for helping you when starting up, operating and storing the unit. The guide are subdivided into 4 sections, which are represented by symbols:

Α



Before starting DO READ OPERATING INSTRUCTIONS BEFORE USE!

- 1A Unpack accessories
- 2A Filter bag installation
- **3A** Disposal bag installation
- **4A** Hose insert & operations
- **5A** Accessories placement
- **6A** Adaptor plate installation
- **7A** Trolley handle installation





Control/Operation

- 1B Push&Clean filter cleaning system
- 2B InfiniClean filter cleaning system
- **3B** Cable and hose storage



Connecting electrical appliances

1C - Power tool adaption





Maintenance:

- 1D Filter bag replacement
- 2D Disposal bag replacement
- **3D** Filter replacement
- 4D Motor cooling air diffuser cleaning
- 5D Gaskets and floater cleaning

Contents

| 1 | Safet | y instructions | 2 |
|---|-------|---|-----|
| | 1.1 | Symbols used to mark instructions | . 2 |
| | 1.2 | Instructions for use | |
| | 1.3 | Purpose and intended use | . 2 |
| | 1.4 | Electrical connection | . 2 |
| | 1.5 | Extension lead | . 2 |
| | 1.6 | Guarantee | . 3 |
| | 1.7 | Important warnings | . 3 |
| 2 | Risks | | |
| | 2.1 | Electrical components | |
| | 2.2 | Hazardous dust | |
| | 2.3 | Spare parts and accessories | . 5 |
| | 2.4 | In explosive or inflammable atmosphere | . 5 |
| 3 | Cont | rol / Operation | |
| | 3.1 | Starting and operating of the machine | |
| | 3.2 | Auto-On/Off socket outlet for power tools*) | |
| | 3.3 | Push&Clean*) | |
| | 3.4 | InfiniClean*) | |
| | 3.5 | Antistatic connection*) | . 6 |
| | 3.6 | Cooling air filter | |
| | 3.7 | Wet pick-up | |
| | 3.8 | Dry pick-up | . 7 |
| 4 | After | using the machine | 7 |
| | 4.1 | After use | . 7 |
| | 4.2 | Transport | . 7 |
| | 4.3 | Storage | |
| | 4.4 | Accessory and tool storage | |
| | 4.5 | Recycling the machine | . 7 |
| 5 | Main | tenance | |
| | 5.1 | Regular servicing and inspection | |
| | 5.2 | Maintenance | . 8 |
| 6 | Furth | ner information | 8 |
| | 6.1 | EU Declaration of conformity | |
| | 6.2 | Specifications | . 9 |
| | | | |



1 Safety instructions



This document contains the safety information relevant for the appliance along with a quick reference guide. Before starting up your machine for the first time, this instruction manual must be read through carefully. Save the instructions for later use.

Further support

Further information on the appliance can be found on our web site at www.Nilfisk.com.

For further queries, please contact the Nilfisk service representative responsible for your country. See reverse of this document.

1.1 Symbols used to mark instructions

DANGER



Danger that leads directly to serious or irreversible injuries, or even death.

WARNING



Danger that can lead to serious injuries or even death.

CAUTION



Danger that can lead to minor injuries and damage.

1.2 Instructions for use

The appliance must:

- only be used by persons, who have been instructed in its correct usage and explicitly commissioned with the task of operating it
- · only be operated under supervision
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.
- Children shall be supervised to make sure that they do not play with the appliance.
- Do not use any unsafe work techniques.
- Never use the appliance without a filter.
- Switch off the appliance and disconnect the mains plug in the following situations:
 - Prior to cleaning and servicing
 - Prior to replacing components
 - Prior to changing over the appliance
 - If foam develops or liquid emerges

Besides the operating instructions and the binding accident prevention regulations valid in the country of use, observe recognised regulations for safety and proper use.

For Dust Class L machines (with type designation -0L, -2L) following applies:

Before starting work, the operating staff must be informed on and trained within:

use of the machine

- risks associated with the material to be picked up
- safe disposal of the picked up material

1.3 Purpose and intended use

This mobile dust extractor is designed, developed and rigorously tested to function efficiently and safely when properly maintained and used in accordance with the following instructions.

This machine is intended for commercial use, for example in hotels, schools, hospitals, factories, shops, offices and rental businesses.

This machine is also suitable for industrial use, such as e.g. plants, construction sites and workshops. Accidents due to misuse can only be prevented by those using the machine.

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

The appliance is suitable for picking up dry, non-flammable dust and liquids.

Any other use is considered as improper use. The manufacturer accepts no liability for any damage resulting from such use. The risk for such use is borne solely by the user. Proper use also includes proper operation, servicing and repairs as specified by the manufacturer.

For Dust Class L machines (with type designation -0L, -2L) following applies:

The appliance is suitable for picking up dry, non-flammable dust and liquids, hazardous dusts with OEL¹⁾ value > 1mg/m3.

Dust Class L (IEC 60335-2-69).

The dusts which belong to this class have OEL¹⁾ values > 1mg/m3.



For machines intended for the Dust Class L, the filter material is tested. The maximum degree of permeability is 1% and there is no special requirement for disposal.

For dust extractors, ensure adequate air change rate L, when the exhaust air is returned to the room. Observe national regulations before use.

1.4 Electrical connection

- It is recommended that the machine should be connected via a residual current circuit breaker.
- Arrange the electrical parts (sockets, plugs and couplings) and lay down the extension lead so that the protection class is maintained.
- Connectors and couplings of power supply cords and extension leads must be watertight.

1.5 Extension lead

 As an extension lead, only use the version specified by the manufacturer or one of a higher quality.



2. When using an extension lead, check the minimum cross-sections of the cable:

| Cable lenth | Cross se | ection |
|-------------|---------------------|---------------------|
| | < 16 A | < 25 A |
| up to 20 m | 1.5 mm ² | 2.5 mm ² |
| 20 to 50 m | 2.5 mm ² | 4.0 mm ² |

1.6 Guarantee

Our general conditions of business are applicable with regard to the guarantee.

Unauthorised modifications to the appliance, the use of incorrect brushes in addition to using the appliance in a way other than for the intended purpose exempt the manufacturer from any liability for the resulting damage.

1.7 Important warnings

WARNING



- To reduce the risk of fire. electric shock, or injury, please read and follow all safety instructions and caution markings before use. This machine is designed to be safe when used for cleaning functions as specified. Should damage occur to electrical or mechanical parts, the machine and / or accessory should be repaired by a competent service center or the manufacturer before use in order to avoid further damage to the machine or physical injury to the user.
- Do not leave the machine when it is plugged in. Unplug from the socket when not in use and before maintenance.

- Outdoor use of the appliance shall be limited to occasional use.
- Do not use with damaged cord or plug. To unplug grasp the plug, not the cord. Do not handle plug or machine with wet hands. Turn off all controls before unplugging.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run machine over cord. Keep cord away from heated surfaces.
- Keep hair, loose clothing, fingers and all parts of the body away from openings and moving parts. Do not put any objects into openings or use with opening blocked. Keep openings free of dust, lint, hair, and anything else that could reduce the flow of air.
- Do not use in outside areas at low temperature.
- Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.
- Do not pick up anything



- that is burning or smoking, such as cigarettes, matches or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use unless filters are fitted.
- If the machine is not working properly or has been dropped, damaged, left outdoors, or dropped into water, return it to a service center or dealer.
- If foam or liquid escapes from the machine, switch off immediately.
- The machine may not be used as a water pump.
 The machine is intended for vacuuming air and water mixtures.
- Connect the machine to a properly earthed mains supply. The socket outlet and the extension cable must have an operative protective conductor.
- Provide for good ventilation at the working place.
- Do not use the machine as a ladder or step ladder. The machine can tip over and become damaged. Danger of injury.
- For standard machines (with type designation -01, -21) following ap-

- plies: This machine is not suitable for picking up hazardous dust.
- Only use the socket outlet on the machine for purposes specified in the instructions.

2 Risks

2.1 Electrical components

DANGER

 \triangle

The upper section of the machine contains live components.

Contact with live components leads to serious or even fatal injuries.

Never spray water on to the upper section of the machine.

DANGER



Electric shock due to faulty mains connecting lead.
Touching a faulty mains connecting lead can result in serious or even fatal injuries.

- Do not damage the mains power lead (e.g. by driving over it, pulling or crushing it).
- Regularly check whether the power cord is damaged or shows signs of ageing.
- If the electric cable is damaged, it must be replaced by an authorized



Nilfisk distributor or similar qualified person in order to avoid a hazard.

 In no circumstances should the power supply cord be wrapped around fingers or any part of the operators person.

2.2 **Hazardous dust**

WARNING

Hazardous materials. Vacuuming up hazardous materials can lead to serious or even fatal injuries. The following materials must not be picked up by the machine:

- hot materials (burning) cigarettes, hot ash, etc.)
- · flammable, explosive, aggressive liquids (e.g. petrol, solvents, acids, alkalis, etc.)
- · flammable, explosive dust (e.g. magnesium or aluminium dust, etc.)

For standard machines (with type designation -01, -21) following further applies: The following materials must not be picked up by the machine:

Hazardous dust

Spare parts and accessories 2.3

CAUTION



Spare parts and accessories.

The use of non-genuine spare parts, brushes and accessories can impair the safety and or function of the appliance.

Only use original spare parts and accessories from

Nilfisk. Spare parts that can affect health and safety of the operator and or function of the appliance, are specified below:

| Description | Order No. |
|--------------------------------------|-----------|
| Flat filter PTFE, 1 pcs. | 107413540 |
| Fleece filter bag, 5 pcs. | 107413547 |
| Disposal bag, 5 pcs. | 107417821 |
| Long Life filter bag, 1 pcs. | 107413556 |
| Motor cooling air filter PET, 1 pcs. | 107413541 |

2.4 In explosive or inflammable atmosphere **CAUTION**

This machine is not suitable for use in explosive or inflammable atmospheres or where such atmospheres are likely to be produced by the presence of volatile liquid or inflammable gas or vapour.

Control / Operation

CAUTION



Damage due to unsuitable mains voltage. The appliance can be damaged as a result of being connected to an unsuitable mains voltage.

Ensure that the voltage shown on the rating plate corresponds to the voltage of the local mains power supply.

3.1 Starting and operating of the machine

Check that the electrical switch is switched off (in position 0). Check that suitable filters are installed in the machine. Then connect the suction hose into the suction inlet at the machine by pushing the hose forward until it fits firmly in place at the inlet. Then connect the tubes with the hose handle, twist the tubes in order to ensure that they are properly fitted. Attach suitable nozzle to the tube. Choose nozzle depending on what type of material that is to be picked-up. If used for dust extraction in connection with dust producing tool then connect end of suction hose with appropriate adapter. Connect the plug into a proper electrical outlet. Put the electrical switch into position I in order to start the motor.



Turn I: Activate the machine Turn 0: Stop the machine



Turn I: Activate the machine turn clock wise for speed control Turn 0: Stop the machine Turn **F**⁻ : Activate Auto-On/Off operation - turn counterclockwise for speed control.





Turn I: Activate the machine Turn ♥/0: Stop the machine. Permanent power on socket. Turn ┡─: Activate Auto-On/Off operation.

Turn I+ Off: Activate the machine with deactivated automatic filter cleaning function

Turn -+ Off: Activate AutoOn/Off operation with deactivated automatic filter cleaning function.

Speed control operation on separate turning knob

3.2 Auto-On/Off socket outlet for power tools⁷

CAUTION



Appliance socket.*

The appliance socket is designed for electrical auxiliary equipment; see technical data for reference.

- Prior to plugging in an appliance, always switch off the machine and the appliance that is to be connected.
- Read the operating instructions to the appliance to be connected and observe the safety notes contained in these.

The maximum power consumption of the connected electrical appliance is stated in section "Specifications".

Before turning the switch to position ensure that the tool connected to the appliance socket is switched off.

3.3 Push&Clean*)

The "PC" machine is equipped with a semi automatic filter cleaning system, Push&Clean. The filter cleaning system must be actuated latest when the suction performance is no longer sufficient. Regular use of the filter cleaning feature maintains suction performance and increases the lifetime of the filter. For instruction see quick reference guide.

3.4 InfiniClean*)

The "IC" machine is equipped with an automatic filter cleaning system, InfiniClean. A frequent cleaning cycle will automatically run during operation to ensure that suction performance is always at its best. If suction performance decreases or in extensive

dust applications a manually filter cleaning operation is recommended:

- · Switch off the machine
- Close the nozzles or suction hose opening with the palm of your hand.
- Turn the switch to position "I" and let the machine operate at full speed for approx. 10 seconds with the suction hose opening closed.

If suction power is still reduced take out the filter and clean mechanically or replace filter.

For certain applications, like wet pick up, it is recommended to turn off the automatic filter cleaning system. For details see chapter 3.1.

3.5 Antistatic connection*)

CAUTION



The machine is equipped with an antistatic system to discharge any static electricity that may develop during dust pick-up.

The antistatic system is placed in front part of the motor top and creates an earth ground connection to the inlet fitting of the container. For proper function the use of an electrical conductive or antistatic suction hose is recommended. When inserting the optional disposal bag make sure the antistatic connection is kept.

3.6 Cooling air filter

To protect the electronics and motor, the machine is equipped with a cooling air diffusor. Clean the cooling air diffusor regularly.

For areas with a high concentration of fine dust in the surrounding air it is recommended to equip the machine with an optional cooling air filter cartridge to prevent dust from settling inside the air channels and motor. Contact your local sales representative.

CAUTION



If cooling air filter is clogged by dust the overload protection switch in the motor can be activated. In such case switch off the machine, clean cooling air filter and allow machine to cool for approx. 5 minutes.

3.7 Wet pick-up

CAUTION



The machine is equipped with a water level limit system which shuts off the machine when the maximum liquid level is reached. When this occurs, switch off the machine. Disconnect the machine from the socket and empty the container. Never pick up liquids without the water level limit system and filter in place.

Picking up liquids.

- Do not pick up flammable liquids
- Before liquids are picked up, always remove the filter bag/wastebag and check that the water level limit works properly.



- If foam appears, stop work immediately and emty the tank.
- Clean the water level limiting device regularly and check for signs of damage.

Before emptying the container, unplug the machine. Disconnect the hose from the inlet by pulling out the hose. Release the latch by pulling them outwards so that the motor top is released. Lift up the motor top from container. Always empty and clean the container and water level limit system after picking-up

Empty by tilting the container backwards or sideways and pour the liquids into a floor drain or similar. Put back the motor top to the container. Secure the motor top with the latches.

Heavy maneuvers can, by mistake, trigger the water level limiting device. Should this happen; turn off the machine and wait for 3 seconds to reset the device. Continue to operate the machine afterwards.

3.8 Dry pick-up

CAUTION



Picking up environmentally hazardous materi-

Materials picked up can present a hazard to the environment.

Dispose of the dirt in accordance with legal regulations.

Remove the electrical plug from the socket before emptying after dry pick-up. Release the latch by pulling them outwards so that the motor top is released. Lift up the motor top from container. Filter: Check the filters. To clean the filter you can shake, brush or wash it. Wait until the filter is dry before re-starting dust pick-up. Dust bag: check bag to ensure the fill factor. Replace dust bag if necessary. Remove the old bag. The new bag is fitted by passing the cardboard piece with the rubber membrane through the vacuum inlet. Make sure that the rubber membrane is passing past the heightening at the vacuum inlet.

After emptying: close motor top to the container and secure the motor top with the latches. Never pick up dry material without filter fitted in the machine. The suction efficiency of the machine depends on the size and quality of the filter and dust bag. Therefore - use only Original filter and dust bags.

After using the machine

After use

Remove the plug from the socket when machine is not in use. Wind up the cord starting from the machine. The power cord can be wound up around the motor top or at the container or placed in the included hook, or fastening means. Some variants have special storage places for accessories.

4.2 **Transport**

- Before transporting the machine, close all the
- Do not tilt the machine if there are liquids in the dirt tank.
- Do not use a crane hook to lift the machine.
- Do not lift the machine by the trolley handle *)

4.3 **Storage**



Store the appliance in a dry place, protected from rain and frost. The machine shall be stored indoors only.

CAUTION

Accessory and tool storage 4.4

For convenient transport and storage of accessories or tools, integrated rails are found on side of machine which allows fastening with straps or other means. A flexible strap and hooks are included on back of machine for attachment of suction hose or mains cable. For instruction see quick reference guide.

An optional adapter plate*) with attachment system can be installed on top of machine for fastening of 2-point or 4-point storage cases.

Remove the electrical plug from the socket before installing the adapter plate.

CAUTION")



Do not lift machine in adapter plate without having storage case safely installed. Note the weight and balance of the appliance in case of storage. Maximum weight of storage cases is 30 kg.

4.5 Recycling the machine

Make the old machine unusable.

- 1. Unplug the machine.
- Cut the power cord.
- 3. Do not discard of electrical appliances with household waste.



As specified in European Directive 2012/19/EU on old electrical and electronic appliances, used electrical goods must be collected separately and recycled ecologically.

5 Maintenance

Regular servicing and inspection

Regular servicing and inspection of your machine must be carried out by suitably qualified personnel in accordance with relevant legislation and regulations. In particular, electrical tests for earth continuity, insulation resistance, and condition of the flexible cord should be checked frequently.

In the event of any defect, the machine MUST be withdrawn from service, completely checked and repaired by an authorized service technician.



At least once a year, a Nilfisk technician or an instructed person must perform a technical inspection including filters, air tightness and control mechanisms.

5.2 Maintenance

Remove the plug from the socket before performing maintenance. Before using the machine make sure that the frequency and voltage shown on the rating plate correspond with the mains voltage.

The machine is designed for continuous heavy work. Depending on the number of running hours – the dust filter should be renewed. Keep the machine clean with a dry cloth, and a small amount of spray polish.

For Dust Class L machines (with type designation -0L, -2L) following applies:

During maintenance and cleaning, handle the machine in such a manner that there is no danger for maintenance staff or other persons.

In the maintenance area

- Use filtered compulsory ventilation
- Wear protective clothing
- Clean the maintenance area so that no harmful substances get into the surroundings.

During maintenance and repair work all contaminated parts that could not be cleaned satisfactorily must be:

- · Packed in well sealed bags
- Disposed of in a manner that complies with valid regulations for such waste removal.

For details of after sales service contact your dealer or Nilfisk service representative responsible for your country. See reverse of this document.

6 Further information

6.1 EU Declaration of conformity

Nilfisk A/S Kornmarksvej 1 DK-2605 Broendby DENMARK

Hereby declare, that the Product VAC - Commercial - Wet/Dry Description 220-240V, 110-120V 50/60Hz, IPX4 Type ATTIX 33-**-**, ATTIX 44-**-** 1)

Are in compliance with the following standards:

EN 60335-1:2012+A11:2014

EN 60335-2-69:2012

EN 55014-1:2006+A1:2009+A2:2011

EN 55014-2:2015

EN 61000-3-2:2014

EN 61000-3-3:2013

Following the provisions of:

2006/42/EC

2014/30/EU

Hadsund 25-10-2017

Anton Sørensen

Senior Vice President - Global R&D

1) First asterisk means feature class.

0 = Standard/Basic type; 2 = Auto on/off for power outlet.

Second asterisk means variants and special types (e.g. dust class). M = Dust Class M, H = Dust Class H. Third and fourth asterisk means filter cleaning options. PC = Push&Clean; IC = InfiniClean



6.2 Specifications

| | | | | | | | ++v | T- | / / / / / / / / / / / / / / / / / / / | | | | | | | |
|--|--------------------|--------------|----------------------|----------------------|--------------|----------------------|----------------------|----------------------|---------------------------------------|----------------------|----------------------|----------------------|------------------|----------------------|-----------------|------------------|
| | | | | | | | - K | AI IIA 55, AI IIA 44 | 17 44 | | | | | | | |
| | | | EU, FR | | | DK/CH/AU/NZ | 7. | | GB 230V | | GB | GB 110V | | SN | | <u>ط</u> |
| | | 33-01 IC | 33-2L PC 33-2L IC | 44-2L PC 44-2L IC | 33-01 IC | 33-2L PC 33-2L IC | 44-2L PC 44-2L IC | 33-01 IC | 33-2L PC 33-2L IC | 44-2L PC 44-2L IC | 33-2L PC 33-2L IC | 44-2L PC 44-2L IC | 33-01 IC | 33-21 PC 33-21 IC | 44-21 PC 3 | 33-01 IC |
| Possible voltage | ^ | 220-240 | 220-240 | 220-240 | 220-240 | 220-240 | 220-240 | 220-240 | 220-240 | 220-240 | 110-120 | 110-120 | 110-120 | 110-120 | 110-120 | 100 |
| Power P _{IEC} | ≥류 | 1200 | 1200 | 1200 | 1200 | 1200 | 1200 | 1200 | 1200 | 1200 | 1000 | 1000 | 1,34 | 890/7,4A 1,2 | 890/7,4A 1,2 | 1200 |
| Connected load for appliance socket | M | - | 2400 | 2400 | - | 1100 | 1100 | - | 1700 | 1700 | 750 1750 | 750 1750 | - | 550/4,6A | 550/4,6A | - |
| Mains frequency | Hz | 20/60 | 20/60 | 20/60 | 20/60 | 09/09 | 09/09 | 09/09 | 20/60 | 09/09 | 09/09 | 20/60 | 20/60 | 20/09 | 20/60 | 20/60 |
| Fuse | A | 16 | 16 | 16 | 10 | 10 | 10 | 13 | 13 | 13 | 16 25 | 16 25 | 15 | 15 | 15 | 12 |
| Protection grade (moist, dust) | | | | | | | | | IPX4 | | | | | | | |
| Protection class (electrical) | | | | | | | | | _ | | | | | | | |
| Max. Airflow* | l/s m³/h CFM | | | | | 75 270 159 | | | | | | | 70 252 148 | | | 70 252 148 |
| Max. Vacuum | kPa hPa in | | | | | 25 250 100 | | | | | | | 23 230 92 | | | 25 250 100 |
| Sound pressure level L _{PA} (IEC 60335-2-69) | dB(A) | | | | | | | | 69 ± 2 | | | | | | | |
| Working sound level | dB(A) | | | | | | | | 60 ± 2 | | | | | | | |
| Vibration ISO 5349 a _h | m/s ² | | | | | | | | ≥ 2,5 | | | | | | | |
| Weight | kg P | 14,5 31,9 | 14,5 31,9 | 16 35,3 | 14,5 31,9 | 14,5 31,9 | 16 35,3 | 14,5 31,9 | 14,5 31,9 | 16 35,3 | 14,5 31,9 | 16 35,3 | 14,5 31,9 | 14,5 31,9 | 16 35,3 | 14,5 31,9 |
| Filter surface area | m ² | | | | | | | | 0,5 | | | | | | | |
| Dust class | | ı | _ | _ | , | _ | _ | , | _ | _ | _ | ٦ | , | , | | , |
| | | | | | | | | | | | | | | | | |

* measured at turbine

Specifications and details are subject to change without prior notice.



HEAD QUARTER

DENMARK

Nilfisk A/S Kornmarksvej 1 DK-2605 Broendby Tel.: (+45) 4323 8100 www.nilfisk.com

SALES COMPANIES

ARGENTINA

Nilfisk srl.
Edificio Central Park
Herrera 1855, 6th floor/604 Ciudad de Buenos Aires Tel.: (+54) 11 6091 1571 www.nilfisk.com.ar

AUSTRALIA

Nilfisk Pty Ltd Unit 1/13 Bessemer Street Blacktown NSW 2148 Tel.: (+61) 2 98348100 www.nilfisk.com.au

AUSTRIA

Nilfisk GmbH Metzgerstrasse 68 5101 Bergheim bei Salzburg Tel.: (+43) 662 456 400 90 www.nilfisk.at

BELGIUM

Nilfisk n.v-s.a. Riverside Business Park Boulevard Internationalelaan 55 Bâtiment C3/C4 Gebouw Bruxelles 1070 Tel.: (+32) 24 67 60 50 www.nilfisk.be

BRAZIL

Nilfisk do Brasil Nillisk do Brasil Av. Eng. Luis Carlos Berrini, 550 40 Andar, Sala 03 SP - 04571-000 Sao Paulo Tel.: (+11) 3959-0300 / 3945-4744 www.nilfisk.com.br

CANADA

Nilfisk Canada Company Value Canada Company 240 Superior Boulevard Mississauga, Ontario L5T 2L2 Tel.: (+1) 800-668-8400 www.nilfisk.ca

CHILE

Nilfisk S.A. (Comercial KCS Ltda) Salar de Llamara 822 8320000 Santiago Tel.: (+56) 2684 5000 www.nilfisk.cl

CHINA

Nilfisk 4189 Yindu Road Xinzhuang Industrial Park 201108 Shanghai Tel.: (+86) 21 3323 2000 www.nilfisk.cn

CZECH REPUBLIC

Nilfisk s.r.o. VGP Park Horní Počernice Do Čertous 1/2658 193 00 Praha 9 Tel.: (+420) 244 090 912 www.nilfisk.cz

DENMARK

Nilfisk Danmark A/S Industrivej 1 Hadsund, DK-9560 Tel.: 72 18 21 20 www.nilfisk.dk

FINLAND

Nilfisk Oy Ab Koskelontie 23 E 02920 Espoo Tel.: (+358) 207 890 600 www.nilfisk.fi

FRANCE

Nilfisk SAS 26 Avenue de la Baltique Villebon sur Yvette 91978 Courtabouef Cedex Tel.: (+33) 169 59 87 00 www.nilfisk.fr

GERMANY

Nilfisk GmbH Guido-Oberdorfer-Straße 2-10 89287 Bellenberg Tel.: (+49) (0)7306/72-444 www.nilfisk.de

GREECE

Nilfisk A F Αναπαύσεως 29 Κορωπί Τ.Κ. 194 00 Tel.: (30) 210 9119 600 www.nilfisk.gr

HOLLAND

Nilfisk B V Versterkerstraat 5 1322 AN Almere Tel.: (+31) 036 5460760 www.nilfisk.nl

HONG KONG

Nilfisk Ltd. 2001 HK Worsted Mills Industrial Building 31-39, Wo Tong Tsui St. Kwai Chung, N.T. Tel.: (+852) 2427 5951 www.nilfisk.com

HUNGARY

Nilfisk Kft. II. Rákóczi Ferenc út 10 Tel.: (+36) 24 475 550 www.nilfisk.hu

Nilfisk India Limited Pramukh Plaza, 'B' Wing, 4th floor, Unit Cardinal Gracious Road, Chakala Andheri (East) Mumbai 400 099 Tel.: (+91) 22 6118 8188 www.nilfisk.in

IRELAND

Nilfisk 1 Stokes Place St. Stephen's Green Dublin 2 Tel.: (+35) 3 12 94 38 38 www.nilfisk.ie

Nilfisk SpA Strada Comunale della Braglia, 18 26862 Guardamiglio (LO) Tel.: (+39) (0) 377 414021 www.nilfisk.it

JAPAN Nilfisk Inc.

Tel-6-6 Kita-shinyokohama, Kouhoku-ku Yokohama, 223-0059 Tel.: (+81) 45548 2571 www.nilfisk.com

MALAYSIA

Nilfisk Sdn Bhd Sd 33, Jalan KIP 10 Taman Perindustrian KIP Sri Damansara 52200 Kuala Lumpur Tel.: (60) 3603 627 43 120 www.nilfisk.com

Nilfisk de Mexico, S. de R.L. de C.V. Pirineos #515 Int. 60-70 Microparque Industrial WSantiago 76120 Queretaro Tel.: (+52) (442) 427 77 00 www.nilfisk.com

NEW ZEALAND

Nilfisk Limited Suite F, Building E 42 Tawa Drive 0632 Albany Auckland Tel.: (+64) 9 414 1996 Website: www.nilfisk.com

NORWAY

Nilfisk AS Bjørnerudveien 24 1266 Oslo Tel.: (+47) 22 75 17 80 www.nilfisk.no

PERU Nilfisk S.A.C. Calle Boulevard 162, Of. 703, Lima 33-Perú Tel.: (511) 435-6840 www.nilfisk.com

POLAND

Nilfisk Sp. Z.O.O. Millenium Logistic Park ul. 3 Maja 8, Bud. B4 05-800 Pruszków Tel.: (+48) 22 738 3750 www.nilfisk.pl

PORTUGAL

Nilfisk Lda. Sintra Business Park Zona Industrial Da Abrunheira Edificio 1, 1° A P2710-089 Sintra Tel.: (+351) 21 911 2670 www.nilfisk.pt

RUSSIA

Nilfisk LLC Vyatskaya str. 27, bld. 7/1st 127015 Moscow Tel.: (+7) 495 783 9602 www.nilfisk.ru

SINGAPORE

Den-Sin 22 Tuas Avenue 2 639453 Singapore Tel.: (+65) 6268 1006 www.densin.com

SLOVAKIA

Nilfisk s.r.o. Bancíkovej 1/A SK-821 03 Bratislava Tel.: (+421) 910 222 928 www.nilfisk.sk

SOUTH AFRICA

Nilfisk (Pty) Ltd Kimbult Office Park 9 Zeiss Road Laser Park Honeydew Johannesburg Tel: +27118014600 www.nilfisk.co.za

SOUTH KOREA

Nilfisk Korea 3F Duksoo B/D, 317-15 Sungsoo-Dong 2Ga Sungdong-Gu, Seoul Tel.: (+82) 2497 8636 www.nilfisk.co.kr

SPAIN

Nilfisk S.A Torre d'Ara, Passeig del Rengle, 5 Plta. 10ª 08302 Mataró Tel.: (34) 93 741 2400 www.nilfisk.es

SWEDEN

Nilfisk AB Taljegårdsgatan 4 431 53 Mölndal Tel.: (+46) 31 706 73 00 www.nilfisk.se

SWITZERLAND

Nilfisk AG Ringstrasse 19 Kircheberg/Industri Stelz Tel.: (+41) 71 92 38 444 www.nilfisk.ch

TAIWAN

Nilfisk Ltd Taiwan Branch (H.K)
No. 5, Wan Fang Road Taipei Tel.: (+88) 6227 00 22 68 www.nilfisk.tw

THAILAND

Nilfisk Co. Ltd. Nillisk Co. Ltd. 89 Soi Chokechai-Ruammitr Viphavadee-Rangsit Road Ladyao, Jatuchak, Bangkok 10900 Tel.: (+66) 2275 5630 www.nilfisk.co.th

TURKEY

Nilfisk A.S Serifali Mh. Bayraktar Bulv. Sehit Sk. No:7 Ümraniye, 34775 Istanbul Tel.: +90 216 466 94 94 www.nilfisk.com.tr

UNITED ARAB EMIRATES Nilfisk Middle East Branch

SAIF-Zone P.O. Box 122298 Sharjah Tel.: (+971) (0) 655-78813 www.nilfisk.com

UNITED KINGDOM

Nilfisk Ltd. Nilfisk House, Bowerbank Way Gilwilly Industrial Estate, Penrith Cumbria CA11 9BQ Tel: (+44) (0) 1768 868995 www.nilfisk.co.uk

UNITED STATES

Nilfisk, Inc. 9435 Winnetka Ave N, Brooklyn Park MN- 55445 www.nilfisk.com

VIETNAM

Nilfisk Vietnam No. 51 Doc Ngu Str. P. Vinh Phúc, Q.Ba Dinh Hanoi Tel.: (+84) 761 5642 www.nilfisk.com

